


Item Number	Quantity	Description	Part Number
2	1	Washer, #14 Brass	7178
3	1	Post	7155
4	2	1/4" Washer	7148
5	1	Paper Spool, Shaft	7159
6	3	Band Adaptor	7157
7	1	Creaser Screw	7335
8	0	Plunger Cup Assembly	7288
9	3	6-32 x 3/16 FH Screw	7170
10	1	Main Tube	7166
11	1	Cotter Pin	7116
12	4	Block, Band Clamp	8109
13	1	Creaser Trigger	7165
14	1	Creaser connector Assembly	7198
15	1	Tape Roll Keeper	7162
16	8	#5-40 X 10 3mm BH Screw	7154
17	1	Nut, Bracket	7320
18	1	Tape Spool	7164
19	1	Band	7158
20	1	Tube Protector	7169
21	3	Band	7171
22	1	Post Socket	2161
23	3	1/4-20 X 12.5mm FLH Screw, Phillips	7160
24	1	Plunger	7130
25	2	1/4-20 Hex Nut	7135
28	1	Cable Assembly	7137
29	2	1/4 Plastic Washer	7000
30	1	1/4-20 Hex Hd Screw	7134
31	1	Plunger Cup	7132
32	1	Washer, Plunger Cup	7133



Reproduction and Distribution
 of this document is prohibited
 without the express written
 permission of the manufacturer.
 © 2007, 2008, 2009, 2010
 by the manufacturer. All rights reserved.



Taper Tube Assembly

12-07	7563	B
-------	------	---